

## WaterColors Color Modes

14 Color Modes

Color Sequence



**Alpine White**



**Sky Blue**



**Cobalt Blue**



**Caribbean Blue**



**Spring Green**



**Emerald Green**



**Emerald Rose**



**Magenta**



**Violet**



**Slow Color Splash**



**Fast Color Splash**



**America the Beautiful**



**Fat Tuesday**



**Disco Tech**

## WaterColors Operation

**Changing Color Mode:** From ON, Turn the light OFF, then ON again within 3 seconds.

**Reset to Alpine White:** From ON, turn the light OFF, then wait 5 seconds to turn the light ON again.

**NOTE:** If off for more than 7 seconds, light will return to last used color when turned on again.

For the best experience, and direct color selection, ask your pool pro about AquaLink® pool and spa controls.

