



HOW TO WINTERIZE YOUR FLOOR SYSTEM





HOW TO WINTERIZE YOUR FLOOR SYSTEM

To winterize a typical pool/spa equipment set, follow the winterizing steps below. *Please note that this step by step tutorial covers the majority of our equipment, but not all. Please adapt and if you still have issues submit an online winterizing service request.



STEP 1

Turn off all power in the breaker box location at the pool equipment.



STEP 2

equipment is above or below pool. If below, turn red or blue shut off valves.



STEP 3

Unscrew black handle on valve pod.



STEP 4

Remove silver band from valve pod.



STEP 5


Lift open tinted lid (do not lose the lids gasket).

Turn off all breakers at pool equipment.





Identify if your pool equipment is below or above your pool's water level.







If your pool equipment is below your pool's water level turn all LARGE red ball valves off before removing any drain plugs from your equipment.








Unscrew black handle on valve pod





Remove silver band from valve pod





Lift open tinted lid (do not lose the lids gasket)







